

Indoor Unit Operation & Installation Manual

AS052MNERA	AS052MNERAB
AS052MFERA	AS052MFERAB
AS072MNERA	AS072MNERAB
AS072MFERA	AS072MFERAB
AS092MNERA	AS092MNERAB
AS092MFERA	AS092MFERAB
AS122MNERA	AS122MNERAB
AS122MFERA	AS122MFERAB
AS162MNERA	
AS162MFERA	
AS182MNERA	
AS182MFERA	
AS242MNERA	
AS242MFERA	
AS282MNERA	
AS302MNERA	

No. 0150524921 D

- Please read this manual carefully before using
- Keep this operation manual for future reference

Original instructions

User Manual

Your air conditioner may be subject to any change owing to the improvement of Haier products.

MRV series multiple air conditioner systems adopt the consistent running mode, by which, all indoor units can only be heating or refrigerating operation at the same time.

To protect the compressor, the air conditioner unit should be powered on for over 12 hours before using it.

All indoor units of the same refrigerating system should use the unified power switch to ensure that all indoor units are in the state of being powered on at the same time during the operation of air conditioner.

Contents

Parts and Functions	1
Safety	2
Emergency Running & Test operation	6
Maintenance	7
Fault Checkup	9
Installation Procedures	10
Electrical Wiring	15
Test Run	21
Fault Code	22
Move and scrap the air conditioning	23

Warning

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The appliances are not intended to be operated by means of an external timer or separate remote-control system.
- Keep the appliance and its cord out of reach of children less than 8 years.

Product Features


1. Hanging-style installation to save space;
2. Automatic display of faults;
3. Function of central control, wired control, wireless control (optional from our company).
4. The air conditioner is provided with the function of compensation for power supply. During operation, when the power supply fails emergently and resumes again, the air conditioner returns to the working condition before power failure, if provided with compensation function.
5. The operating methods and functions are same although the shapes of indoor units are different. Therefore, the outline drawing of AS072MNERA indoor unit is taken as an example for illustration.

Operating Range of Air Conditioner

cooling dry	indoor	max.	DB: 32°C WB: 23°C
		min.	DB: 18°C WB: 14°C
	outdoor	max.	DB: 43°C WB: 26°C
		min.	DB: -5°C
heating	indoor	max.	DB: 27°C
		min.	DB: 15°C
	outdoor	max.	DB: 21°C WB: 15°C
		min.	DB: -15°C

Parts and Functions


Indoor Unit



Actual inlet grille and display board may vary from the one shown in the manual according to the product purchased.


Display board A

- ① Signal receiver hole
- ② Ambient temp. display
When receiving the remote control signal, display the set temperature.
- ③ COOL display
- ④ HEAT display
- ⑤ HEALTH display
- ⑥ DRY display



Display board B

- ① Remote signal receiver
(A beeping sound is generated when a signal from remote controller is received.)
- ② Power indicator (Lights up when unit starts.)
- ③ Timer mode indicator (Lights up when Timer operation is selected.)
- ④ Operation mode indicator (lights up when the compressor is on.)
- ⑤ Ambient temp display
When receiving the remote control signal, display the set temperature.



Safety

- If the air conditioner is transferred to a new user, this manual shall be transferred to the user, together with the conditioner.
- Before installation, be sure to read Safety Considerations in this manual for proper installation.
- The safety considerations stated below is divided into “⚠ Warning” and “⚠ Attention”. The matters on severe accidents caused from wrong installation, which is likely to lead to death or serious injury, are listed in “⚠ Warning”. However, the matters listed in “⚠ Attention” are also likely cause the severe accidents. In general, both of them are the important items related to the security, which should be strictly abided by.
- After the installation, perform test run to make sure everything is in normal conditions, and then operate and maintain the air conditioner in accordance with the User Manual. The User Manual should be delivered to the user for proper keeping.

Warning

- Please ask the special maintenance station for installation and repair. Water leakage, electric shocks or fire accidents might be caused from improper installation if you conduct the installation by your own.
- The installation should be conducted properly according to this manual. Water leakage, electric shocks or fire accidents might be caused from improper installation.
- Please make sure to install the air conditioner on the place where can bear the weight of the air conditioner. The air conditioner can't be installed on the grids such as the non-special metal burglar-proof net. The place with insufficient support strength might cause the dropdown of the machine, which may lead to personal injuries.
- The installation should be ensured against typhoons and earthquakes, etc. The installation unconformable to the requirements will lead to accidents due to the turnover of the machine.
- Specific cables should be used for reliable connections of the wirings. Please fix the terminal connections reliably to avoid the outside force applied on the cables from being impressed on the cables. Improper connections and fixings might lead to such accidents as heating or fire accidents.
- Correct shapes of wirings should be kept while the embossed shape is not allowed. The wirings should be reliably connected to avoid the cover and the plate of the electrical cabinet lipping the wiring. Improper installation might cause such accidents as heating or fire accidents.
- While placing or reinstalling the air conditioner, except the specific refrigerant (R410A), don't let the air go into the refrigeration cycle system. The air in the refrigeration cycle system might lead to the cracking or personal injuries due to abnormal high pressure of the refrigeration cycle system.
- During installation, please use the accompanied spare parts or specific parts. If not, water leakage, electric shocks, fire accidents or refrigerant leakage might be caused.
- Don't drain the water from the drainpipe to the waterspout where may exist harmful gases such as sulfureted gas to avoid the harmful gases entering into the room.
- During installation, if refrigerant leakage occurs, ventilation measures should be taken, for the refrigerant gas might generate harmful gases upon contacting the flame.
- After installation, check if any refrigerant leakage exists. If the refrigerant gas leaks in the room, such things as air blowing heaters and stoves, etc. may generate harmful gases.



Safety

- Don't install the air conditioner at the places where the flammable gases may leak. In case the gas leakage occurs around the machine, such accidents as fire disasters may be caused.
- The drainpipe should be properly mounted according to this manual as to ensure the smooth drainage. In addition, heat preservation should be taken to avoid condensation. Improper drainpipe mounting might cause water leakage, which will get the articles at home wet.
- The refrigerant gas pipe and liquid pipe should be heat insulated to preserve heat. For inappropriate heat insulation, the water caused from the condensation will drop to get the article at home wet.

Attention


- The air conditioner should be effectively grounded. Electric shocks may occur if the air conditioner is ungrounded or inappropriately grounded. The wire for earthing shouldn't be connected to the connections on the gas pipe, water pipe, lightning rod or telephone.
- The breaker for electricity leakage should be mounted. If not, accidents such as electric shocks may happen.
- The installed air conditioner should be checked for electricity leakage by being powered.
- when the water discharge hole be blocked or the filter becomes dirty, there maybe leads to condensing water drop down, and at the same time there maybe some drops of water spit out.
- In case of ambient dew point temperature greater than 28 degrees Celsius or humidity greater than 80%, there maybe cause condensation drops or blow out, electrical or moisture sensitive items shouldn't be put below.

Safety


	<p>Items with this warning sign concerning the product's safety and the personal security must be performed strictly.</p>
	<p>Items with this forbidding sign refer to absolutely forbidden behaviors. If not, they may cause machine damage or endanger operator's personal safety.</p>

Clean the filter regularly.


Cooling or heating performance will be degraded if the filter is blocked, resulting in large power consumption, failure, and water dripping at freezing.



Don't touch the outlet while the flap is moving. Don't put anything in the grid in case danger may occur.



Avoid cold wind from blowing out. During heating running, the fan of indoor units will not rotate immediately as to prevent cold wind from blowing out.



Changing Wind Speeds:

In the state of refrigerating, with automatic blowing mode, the wind speed automatically decreases when the room temperature approaches the setting.

In the state of heating, when the room temperature reaches the setting temperature the compressor stops working and the fan turns to low wind or stops. Wind speed changes automatically in the dehumidifying mode.

Regulating Wind Direction:

It is recommended not to make the wind deflector downwards for a long time to avoid condensation at air outlet port during refrigerating or dehumidifying.

Water dropping might appear at the air outlet port in refrigerating or dehumidifying mode.

Defrosting:

During heating running, the air conditioner would defrost automatically if there is frost on heat exchanger of outdoor units.

Do not rotate fans of both indoor units and outdoor units during defrosting.

After finishing defrosting, the air conditioner will resume running automatically.

The machine operation must be controlled by the control.



Hints:

















As air conditioners absorb heat from the environment and release it to the room, heating effects will be influenced by the temperature in and out of the room.

Safety



Attention

Notices during Operation

- | | |
|---|--|
| <ul style="list-style-type: none"> • It is not allowed to put any heating apparatus under the indoor units, for the heat may cause distortion of the units. • Pay attention to the aeration condition to avoid anoxic symptom.   • Flammable apparatus should not be placed in the place where the air conditioner wind could reach directly, or incomplete burning of the apparatus may be caused.   • Check the mount table of the air conditioner for damage for a long period of operation. If placed on the damaged table, the unit may drop down causing damage.  • Plants and animals should not be put to the place where wind of the air conditioner blows directly, otherwise damage to them may be caused.  • It cannot be used for the preservation of food, living creature, precise instrument and artworks, etc, otherwise damage may occur.  • Use the fuse with proper capacity. Metal wires and copper wires, etc., may cause fire or other faults.  • Do not use water heater or like next to the indoor unit and the wired controller. Water/power leakage or short circuit may happen if the steam generating apparatus is working next to machine.  • Defrosting during heating
To improve the heating effect, the outdoor unit will perform defrosting automatically when frost appears on the outdoor unit during heating (approximately 2-10 min). During defrosting, the fan of the indoor unit runs at a low speed or stops while that of the outdoor unit stops running. • Power should be cut off when the air conditioner is left unused for a long period. Power will be consumed if the air conditioner is not powered off. The power switch of the outdoor unit switch should be powered on 12 hours in advance before operation to protect the unit after a long period of storage. | <ul style="list-style-type: none"> • 3-minute protection
To protect the unit, compressor can be actuated with at least 3-minute delay after stopping. • Close the window to avoid outdoor air getting in. Curtains or window shutters can be put down to avoid the sunshine.  • Do not touch the switch with the wet hand to avoid power shock.  • Stop running and switch off the manual power switch when cleaning the unit.  • During the operation of the control unit, don't switch off the manual power switch and the controller can be used. Please do not press the liquid crystal zone of controller to prevent damage.  • Cleaning the unit with water may cause electric shock.   • Do not put flammable spray close to the air conditioner. Don't inject flammable spray towards the air conditioner, which may cause fire.  • Stopping fan rotation
The unit which stops operating will actuate the fan for a 2-8 min swing every 30-60 minutes for protecting the unit while other indoor unit are in the operating state. • This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. |
|---|--|

Emergency Running & Test operation

Emergency Running & Test operation:

- Emergency running will help air conditioner operate automatically if your remote control is missing or out of work.
- Test operation is recommended when room temperature is below 16°C but not in normal condition.

Emergency Running

It is recommended to use only when the remote control is missing or damaged.

■ Startup

A warning tone could be heard after turning on the Emergency Running switch, which means that the emergency running gets started.

- Air conditioner operates automatically according to the working modes blow:

Set Temp	Wind Speed	Working Mode
24°C	auto	auto


Temperature setting values and wind speed cannot be changed in the mode of emergency running. Meanwhile, dehumidification and timing operation cannot be operated simultaneously.

■ Shutdown (canceling the emergency running)

All the indicator lamps on the conditioner extinguish after pressing the emergency running switch and hearing the warning tone.

■ Canceling the emergency running with the remote controller

A warning tone is heard after pressing the ON/OFF button on remote controller. The air conditioner works according to the indication of operating state on the remote controller.



Test Operation

It is recommended when the room temperature is below 16°C but not in normal condition.

■ Startup

Press it for over 5 seconds till 2 warning tones are heard and then release your finger to start the test operation. The air conditioner is operating at high wind speed. The test operation lasts for 30 minutes before the air conditioner stops automatically.


■ Shutdown (canceling the test operation)

The warning tones are followed after pressing the test operation switch.

■ Canceling the test operation with the remote controller

The warning tone could be heard after pressing the switch on remote controller.

The air conditioner works according to the indication of operating state on the remote controller.



Maintenance

※Only when the air cleaner is switched off and disconnected to the power supply can it be cleaned, or electric shock and injury may appear.

Cleaning the air outlet port and the shell:

⚠ Attention

- Don't use gasoline, benzene, diluents, polishing powder or liquid insecticide to clean them.
- Do not clean them with hot water of above 50°C to avoid fading or distorting.
- Wipe them with soft dry cloth.
- Water or neutral dry cleanser is recommended if the dust cannot be removed.
- The Wind Deflector can be dismantled to clean (as below).

Cleaning Wind Deflector:

- Do not wipe the wind deflector with water forcibly to avoid falling off.

Cleaning Air Cleaner:

⚠ Attention

- Don't rinse the air cleaner with hot water of above 50°C to avoid fading and distorting.
 - Don't put the air cleaner on the fire to dry to avoid catching fire.
 - Wipe dust with water or dust collector.
- (A) Wipe dust with dust collector.
- (B) Clean it with soft brush in mild detergent if there is too much dust on it



Throw off the water and airing it in the cool dry condition.



Maintenance before and after Operating Season

Before Operating Season:

1. Please make the following checkup. If abnormal condition occurs, consult the after-service personnel.
 - There is no blockage in inlet port and outlet port of outdoor and indoor units.
 - The ground line and the wiring are in the proper state
2. After cleaning, the air cleaner must be mounted.
3. Switch on to the power.

After Operating Season:

1. In sunny days, blowing operation can be performed for half a day to make the inside of machine dry.
2. Electrical power should be cut down to economize electricity, or the machine will still consume power. Air cleaner and shell must be mounted after cleaning.

Maintenance


Clean the machine (Cleaning ways are approximately same, taking AS182MNERA indoor machine as example).

Turn off the air conditioner before cleaning. Do not touch the machine if the hands are wet. Neither hot water nor solvent should be used in cleaning.

Replacement of Air Purifying Filter


1. Open the Inlet Grille

Prop up the inlet grille by using a small device named grille-support which located in the right side of the indoor unit.




2. Detach the standard air filter

Slide the knob slightly upward to release the filter, then withdraw it.




3. Attach Air Purifying Filter

Put air purifying filter appliances into the right and left filter frames.



4. Attach the standard air filter (Necessary installation)



ATTENTION:

The white side of the photocatalyst air purifying filter face outside, and the black side face the unit. The green side of the bacteria-killing medium air purifying filter face outside, and the white side face the unit.

5. Close the Inlet Grille


Close the Grille surely

NOTE:

- The photocatalyst air purifying filter will be solarized in fixed time. In normal family, it will be solarized every 6 months.
- The bacteria-killing medium air purifying filter will be used for a long time, no need for replacement. But in the period of using them, you should remove the dust frequently by using vacuum cleaner or flapping them lightly, otherwise, its performance will be affected.
- Please keep the bacteria-killing medium air purifying filter in the cool and dry conditions, avoid long time directly sunshine when you stop using it, or its ability of sterilization will be reduced.

Fault Checkup

Please check the following when consigning repair service:

	Symptoms	Reasons
All these are not problems	<ul style="list-style-type: none"> • Water flow sound 	Water flow sound can be heard when starting operation, during operation or immediately after stopping operation. When it starts to work for 2-3 minutes, the sound may become louder, which is the flowing sound of refrigerant or the draining sound of condensed water.
	<ul style="list-style-type: none"> • Cracking sound 	During operation, the air conditioner may make the cracking sound, which is caused from the temperature changes or the slight dilation of heat exchanger.
	<ul style="list-style-type: none"> • Terrible smell in outlet air 	The terrible smell, caused from walls, carpet, furniture, clothing, cigarette and cosmetics, attaches on the conditioner.
	<ul style="list-style-type: none"> • Flashing operating indicator 	When switching it on again after power failure, turn on the manual power switch and the operating indicator flashes.
	<ul style="list-style-type: none"> • Awaiting indication 	It displays the awaiting indication as it fails to perform refrigerating operation while other indoor units are in heating operation. When the operator set it to the refrigerating or heating mode and the operation is opposite to the setting, it displays the awaiting indication.
	<ul style="list-style-type: none"> • Sound in shutdown indoor unit or white steam or cold air 	To prevent oil and refrigerant from blocking the shutdown indoor units, refrigerant flows in the short time and make the sounds of refrigerant flowing. Otherwise, when other indoor units performs heating operation, white steam may occur; during refrigerating operation, cold air may appear.
	<ul style="list-style-type: none"> • Clicking sound when switching the air condition on 	When the conditioner is powered on, the sound is made due to the resetting of the expansion valve.
Please make another check.	<ul style="list-style-type: none"> • Start or stop working automatically 	Check if it is in the state of Timer-ON and Timer-OFF.
	<ul style="list-style-type: none"> • Failure to work 	Check if there is a power failure. Check if the manual power switch is turned off. Check if the supply fuse and breaker are disconnected. Check if the protective unit is working. Check if refrigerating and heating functions are selected simultaneously with the awaiting indication on line control.
	<ul style="list-style-type: none"> • Bad cooling & heating effects 	Check if air intake port and air outlet port of outdoor units are blocked. Check if the door and windows are open. Check if the filtering screen of air cleaner is blocked with sludge or dust. Check if the setting of wind quantity is at low wind. Check if the setting of operation is at the Fan Operation state. Check if the temperature setting is proper.

Under the following circumstances, immediately stop the operation, disconnect the manual supply switch and contact the after-service personnel.

- When buttons are inflexible actuated;
- When fuse and breaker have been burnt over and over;
- When there are foreign objects and water in the refrigerator;
- When it cannot still be operated after removing the operation of protective unit;
- When other abnormal conditions occur.

Installation Procedures

This manual cannot completely illustrate all the properties of the products you bought. Please contact the local Haier distribution center if you have any question or request.

Please use the standard tool according to the installation requirements.

The standard attached accessories of the units of this series refer to the packing; prepare other accessories according to the requirements of the local installation point of our company.

1. Choose the suitable installation location. Indoor units should be installed in places with the environment of even circulation of cool and warm blows. The following places should be avoided.

✕ Places with high salinity (beach), high sulfureted gas (such as the thermal spring regions where copper tubes and soft soldering are easy to be eroded), much oil (including mechanical oil) and steam; places where organic substance solvent is frequently used; places where machines generate the high frequency electromagnetic wave (abnormal condition will appear in the control system); places where there is high humidity exists near the door or windows (dew is easily formed); and places where the special sprayer is frequently used.

Indoor Units


- (1) The distance between wind outlet port and the ground should not be more than 2.7m. The distance to streets should not be less than 2.5m.
- (2) Select appropriate places for installation where the outlet air can be spread to places all over the house and arrange proper locations for connecting pipes and lines as well as the drainpipe to the outdoor.
- (3) Ceiling construction must be hard enough to hold the weight of the unit.
- (4) Make sure that the connecting pipe, drainpipe and connecting guide line can be put into walls to connect the outdoor units.
- (5) It is recommended to make the connecting pipe between the outdoor and indoor units and the drainpipe are as short as possible.
- (6) Please read the attached installation instruction of outdoor units for regulation of filling amount of refrigerant if necessary.
- (7) Select a place close to the supply socket of air conditioner and enough space should be kept near the machine.
- (8) Those electrical appliances such as television, instruments, devices, artwork, piano, wireless equipment and other valuables should not be placed under the indoor unit and over 1m away from the daylight lamp as to prevent condensate from dropping into them and causing damage.

2. The following steps can be taken after selecting the installation place:

Cut a hole on the wall and put the connecting pipe and connecting thread into the PVC, which is purchased at the local shop. With a slight downwards tilt towards the exterior, the gradient should be kept at least 1/100. before cutting the hole, check if there are pipes or reinforcing steel bars at the rear of the hole. Making the hole in the place with wires or pipes should be avoided.

Installation Procedures

3.Installation Drawing of Indoor Units:



(1) Positioning Wall Pad & Locating Wall Holes

Fix the pad according to the installation location and the pipe layout of indoor unit (please refer to the installation drawing).

Installation should be done under the crossbeam or on the flat wall near the pillar. First fix the pad with a steel nail on the wall.

Drop a thread with a bolt through the pad center or use a level meter to find the level.

Then fix it with a concrete steel nail, and measure the position of the wall hole A.


(2) Drilling Hole & Mounting Guard Ring

Drill a hole of 60mm bore with a slight tilt downwards to the outside, mount the guard ring, and seal it with gesso or putty after finishing the installation.


(3) Arranging Wiring of Indoor Unit

Arrange the layout of connection pipe, drain pipe, connecting line, signal line and air refreshing pipe according to the locations of your indoor unit, outdoor unit and wall holes, with drainage hose lower, connecting line upper.

Intercrossing winding is not allowed between the mains line and the connecting line, and the drain pipe(especially in the indoor unit and the inside of machine) should be wound with heat insulating materials for heat preservation.



Installation Procedures







(4) Lead the connection tubing(liquid pipe and gas pipe) through the hole into the wall, or connect piping and wiring of indoor unit(check the number of wiring terminals of indoor and outdoor units and connect terminals with the same number and color), and then put the connection tubing and the connecting line through from the inside wall for the connection with outdoor unit.

Fitting of the Mounting Plate and Positioning of the wall Hole


When the mounting plate is first fixed

1. Carry out, based on the neighboring pillars or lintels, a proper leveling for the plate to be fixed against the wall, then temporarily fasten the plate with one steel nail.
2. Make sure once more the proper level of the plate, by hanging a thread with a weight from the central top of the plate, then fasten securely the plate with the attachment steel nail.
3. Find the wall hole location A using a measuring tape.




Pay attention to the following points before installation of machine:

1. Take out cushion blocks on the left and right angle beads as shown in the following Figure.



Installation Procedures

2. Remove 2 gaskets under the cross-flow fan (AS162~242).
3. Clean the burr on the surface of fracture to avoid the power wire from being scratched after removing the virtual opening of the outgoing line slot on the case by hands in indoor power-on process.



When the mounting plate is fixed side bar and lintel

- Fix to side bar and lintel a mounting bar, Which is separately sold, and then fasten the plate to the fixed mounting bar.
- Refer to the previous article, "When the mounting plate is first fixed" for the position of wall hole.

Tubing Permissible Length & Height Difference

Please refer to the attached manual of outdoor units.

Tubing Materials & Specifications

Model		AS05~09	AS12~18	AS24~30
Tubing Size (mm)	Gas pipe	Ø9.52	Ø12.7	Ø15.88
	Liquid pipe	Ø6.35	Ø6.35	Ø9.52
Tubing Material		Phosphor deoxybronze seamless pipe (TP ₂) for air conditioner		


Refrigerant Filling Amount

Add the refrigerant according to the installation instruction of outdoor unit. The addition of R410A refrigerant must be performed with a measure gage to ensure the specified amount or compressor failure can be caused by filling too much or little refrigerant.

Connecting Procedures of Refrigerant Tubing

Proceed the flare tube connecting operation to connect all the refrigerant tubes.

- Dual wrenches must be used in the connection of indoor unit tubing.
- Mounting torque refers to the right table



Outer Diameter of Tubing (mm)	Mounting Torque (N-m)	Increase mounting Torque (N-m)
Ø6.35	11.8(1.2kgf-m)	13.7(1.4kgf-m)
Ø9.52	24.5(2.5kgf-m)	29.4(3.0kgf-m)
Ø12.70	49.0(5.0kgf-m)	53.9(5.5kgf-m)
Ø15.88	78.4(8.0kgf-m)	98.0(10.0kgf-m)
Ø19.05	98.0(10.0kgf-m)	117.7(12.0kgf-m)

Installation Procedures

Cutting and Enlarging

Cutting or enlarging pipes should be proceeded by installation personnel according to the operating criterion if the tube is too long or flare opening is broken.

Vacuumizing

Vacuumize from the stop valve of outdoor units with vacuum pump. Refrigerant sealed in indoor machine is not allowed to use for vacuumization.


Open All Valves

Open all the valves of outdoor units. [NB: oil balancing stop valve must be shut up completely when connected one main unit.]

Checkup for Air Leakage

Check if there is any leakage at the connecting part and bonnet with hydrophone or soapsuds.


Connecting



1. Connecting circular terminals:
The connecting method of circular terminal is shown in the Fig. Take off the screw, connect it to the terminal tier after heading it through the ring at the end of the lead and then tighten it.

2. Connecting straight terminals:
The connection methods for the circular terminals are shown as follows: loosen the screw before putting the line terminal into the terminal tier, tighten the screw and confirm it has been clamped by pulling the line gently.

3. Pressing connecting line
After connecting line is completed, press the connecting line with clips which should press on the protective sleeve of the connecting line.



Installing and Dismantling Indoor Unit

1. Installation

During the installation of this series machines, fasten the wall pad on the wall first, hang the machine on the pothook, push it towards the wall pad until the sound of 'pa' 'pa' is heard. At this time, the agraffes of the indoor unit have hitched on the pad, as shown in the Fig.1 with dotted line.

2. Dismantling

During dismantling this series machines, push agraffes at the bottom of indoor unit upwards to release them, as shown in Fig.3, and pull up the bottom of indoor unit outwards gently and then raise the unit upwards in the bevel direction to release the pothook at the upper part of the wall pad, as shown in Fig.3.




Fig. 1




Fig. 2




Fig. 3




Fig. 4

Electrical Wiring


⚠ Warning

- Electrical construction should be made with specific mains circuit by the qualified personnel according to the installation instruction. Electric shock and fire may be caused if the capacity of power supply is not sufficient. !
- During arranging the wiring layout, specified cables should be used as the mains line, which accords with the local regulations on wiring. Connecting and fastening should be performed reliably to avoid the external force of cables from transmitting to the terminals. Improper connection or fastness may lead to burning or fire accidents. !
- There must be the ground connection according to the criterion. Unreliable grounding may cause electrical shocks. Do not connect the grounding line to the gas pipe, water pipe, lightening rod and telephone line. !

⚠ Attention

- Only copper wire can be used. Breaker for electric leakage should be provided, or electric shock may occur.
- The wiring of the mains line is of Y type. The power plug L should be connected to the live wire and plug N connected to null wire while \oplus should be connected to the ground wire. For the type with auxiliary electrically heating function, the live wire and the null wire should not be misconnected, or the surface of electrical heating body will be electrified. If the power line is damaged, replace it by the professional personnel of the manufacturer or service center.
- The power line of indoor units should be arranged according to the installation instruction of indoor units.
- The electrical wiring should be out of contact with the high-temperature sections of tubing as to avoid melting the insulating layer of cables, which may cause accidents.
- After connected to the terminal tier, the tubing should be curved into be a U-type elbow and fastened with the pressing clip.
- Controller wiring and refrigerant tubing can be arranged and fixed together. !
- The machine can't be powered on before electrical operation. Maintenance should be done while the power is shut down.
- Seal the thread hole with heat insulating materials to avoid condensation.
- Signal line and power line are separately independent, which can't share one line. [Note: the power line, signal line are provided by users. Parameters for power lines are shown as below: $3 \times (1.0-1.5) \text{ mm}^2$; parameters for signal line: $2 \times (0.75-1.25) \text{ mm}^2$ (shielded line)]
- 5 butt lines (1.5mm) are equipped in the machine before delivery, which are used in connection between the valve box and the electrical system of the machine. The detailed connection is displayed in the circuit diagram.


Supply Wiring Drawing



- Indoor units and outdoor units should be connected to the power source separately. Indoor units must share one single electrical source, but its capacity and specifications should be calculated. Indoor & outdoor units should be equipped with the power leakage breaker and the overflow breaker.

Electrical Wiring

Signal Wiring Drawing



The combination of multiple indoor units can be controlled by remote controller.
Note:AS*ERA models are set to remote- controlled type.

The wiring for the power line of indoor unit, the wiring between indoor and outdoor units as well as the wiring between indoor units:

Total Current of Indoor Units(A)	Items	Cross Section (mm ²)	Length (m)	Rated Current of Overflow Breaker(A)	Rated Current of Power Leakage Breaker (A) Leaking Current(mA) Operating Period (S)	Cross Sectional Area of Signal Line	
						Outdoor -indoor (mm ²)	Indoor -indoor (mm ²)
< 7		2.5	20	10	10 A,30 mA,0.1S or below	2 cores×0.75-2.0 mm ² shielded line	
≥7 and <11		4	20	16	16 A,30 mA,0.1S or below		
≥11 and <16		6	25	20	20 A,30 mA,0.1S or below		
≥16 and <22		8	30	32	32 A,30 mA,0.1S or below		
≥22 and <27		10	40	32	32 A,30 mA,0.1S or below		

- ✖ The electrical power line and signal lines must be fastened tightly.
- ✖ Every indoor unit must have the ground connection.
- ✖ The power line should be enlarged if it exceeds the permissible length.
- ✖ Shielded lays of all the indoor and outdoor units should be connected together, with the shielded lay at the side of signal lines of outdoor units grounded at one point.
- ✖ It is not permissible if the whole length of signal line exceeds 1000m.


High wall wired controller wiring and instruction

Two wired controllers control one high wall unit One wired controller controls one high wall unit




Electrical Wiring

Recommended: One wired controller controls more than one indoor unit (limited in high walls)



Not recommended: One wired controller controls more than one indoor unit (ordinary indoors)



High wall wired controller wiring instruction:

1. One wired controller controls one high wall unit (one to one), connect the wires of wired controller to CN22 terminal on PCB directly.
2. Two wired controllers control one high wall unit (two to one), connect the wires of wired controller 1 and 2 respectively to CN22 and CN22-1 on PCB.
3. One wired controller controls more than one unit (one to more), limited in high wall units is recommended and mixed different type indoor units is not recommended . It's easy to do wrong wiring when there're many different type indoors.

If you choose one to more (mixed different type indoor units), please follow the principles below:

- a. The communication wires of wired controller inlet or outlet high wall units are 3 cores. It means to connect all the wires "ABC".
- b. When one wire controller connect to more indoors, all the wires between terminals are 3 cores. When other indoor units are slave ones of wired controller, please move off the "A" wire between indoor and PCB CN22 terminals. It means that when other indoors are slave ones of wired controller, no need to connect "A" wire.
- c. When the "A" wire is not connect to other ordinary indoors which are the slave ones of wired controller, please do some insulation on it and avoid touching other electric circuit.

Electrical Wiring

Dipswitch Setting

- The dipswitch is dialed to "On" position with the overline at the state of strapping if the code or overline status is "1" The dipswitch is dialed to "Off" position with the overline at the state of disconnection if the code or overline status is "0"
- In the table below, the choice in the box " ☐ " refers to the setting of the socket/overline before delivery.

Indoor Units PCB

In the following table, 1 represents On and 0 represents Off.

Definition principles of code switches:

SW01 is used to set wire controlled address of and set capabilities of master;SW03 is used to set indoor unit address (combine original communication address and address of centralized controller)

(A) Definition and description of SW01

SW01_1 SW01_2 SW01_3 SW01_4	Address of wire controlled indoor unit (group address)	[1]	[2]	[3]	[4]	Address of wire controlled indoor unit (group address)
		0	0	0	0	0# (wire controlled master unit) (default)
		0	0	0	1	1# (wire controlled slave unit)
		0	0	1	1	2# (wire controlled slave unit)
		0	0	1	1	3# (wire controlled slave unit)
	
SW01_5 SW01_6 SW01_7 SW01_8	Capability of indoor unit	1	1	1	1	15# (wire controlled slave unit)
		[5]	[6]	[7]	[8]	Capability of indoor unit
		0	0	0	0	0.6HP(AS052)
		0	0	0	1	0.8HP(AS072)
		0	0	1	0	1.0HP(AS092)
		0	0	1	1	1.2HP(AS122)
		0	1	0	0	1.5HP
		0	1	0	1	1.7HP(AS162)
		0	1	1	0	2.0HP(AS182)
		0	1	1	1	2.5HP(AS242)
		1	0	0	0	3.0HP(AS282)
		1	0	0	1	3.2HP(AS302)
		1	0	1	0	4.0HP
		1	0	1	1	5.0HP
		1	1	0	0	6.0HP
		1	1	0	1	8.0HP
		1	1	1	0	10.0HP
		1	1	1	1	15.0HP

Note : A wired controller can connected to at most sixteen ultrathin air-duct indoor units.

Electrical Wiring

(B) Definition and description of SW03

SW03_1	Address setting mode	0	Automatic address setting or wired controller address setting (default)							
		1	Code-set address							
SW03_2 ~ SW03_8	Code-set indoor unit address and centralized controller address (Note 2)	2	3	4	5	6	7	8	Address of indoor unit	Address of centralized controller
		0	0	0	0	0	0	0	0# (Default)	0# (Default)
		0	0	0	0	0	0	1	1#	1#
		0	0	0	0	0	1	0	2#	2#
	
		0	1	1	1	1	1	1	63#	63#
		1	0	0	0	0	0	0	0#	64#
		1	0	0	0	0	0	1	1#	65#
		1	0	0	0	0	1	0	2#	66#
	
		1	1	1	1	1	1	1	63#	127#

Note:

•Set the address by code when connecting the centralized controller or gateway or charge system.

•Address of centralized controller =communication address + 0 or +64.

SW03_2=OFF, address of centralized controller =communication address+0=communication address

SW03_2=ON, address of centralized controller=communication address+64 (applies when centralized controller is used and there are more than 64 indoor units)

•To use with 0010451181A in use, it is required to use code for address setting. Set SW03_1=ON and SW03_2=OFF; SW03_3, SW03_4, SW03_5, SW03_6, SW03_7 and SW03_8 are address codes which are set according to actual address.

•When connecting central controller, gateway or counting system, set address by dip switch.

Electrical Wiring

Special function

1. Emergency switch:

Press the emergency switch in stop condition, indoor unit operate with AUTO, AUTO SPEED, 24 Setting modes, pressure the emergency switch in start condition, indoor unit will stop operation.

2. Temp. consumption:

The heating mode, the temp. compensation range is $-14 \sim 0$.

Set the temp. consumption in Heating mode with remote controller, heating mode ,set 30 as the reference point, press the sleep button 7 times, the buzzer ring 2 times, the unit enter temp. consumption condition. Temp. consumption data=current temp.-30

In the cooling mode, the temp.compensation range is $-7 \sim +7$.

Set the temp. consumption in Cooling mode with remote controller, cooling mode ,set 23 as the reference point, press the sleep button 7 times in 5 seconds, the buzzer ring 2 times, the unit enter temp. consumption condition. Temp. consumption data=current temp.-23.

3. Energy saving setting:

In on condition ,press the health button 8 times within 5 seconds, buzzer short ring 4 times that the energy saving setting is valid, if the buzzer rings 2 times that the energy saving setting is invalid.

4. Compulsive Defrost:

In heating mode, setting high speed ,set temp. is 30 , press sleep button for 6 times, buzzer short ring 3 times, unit enter manual defrost mode.

5. Auto start function:

In on condition ,press the sleep button 10 times within 5 seconds, buzzer short ring 4 times stands for enter auto restart function; press the sleep button 10 times within 5 seconds, buzzer short ring 2 times stands for exit auto restart function .


The memory information: on/off condition, mode, fan speed, setting temp., swing position.

6. Room card Function:

Room card function can realize by remote controller.

Press the light button 12 times with remote controller,if the buzzer rings 4 times that the room card is valid, if the buzzer rings 2 times that the room card is invalid.

7. Health anion function:

In on condition, press the "HEALTH" button, when displaying icon  on LCD display, Air conditioner starts health anion function operation, press the "HEALTH" button again to cancel anion function.

Test Run

Before Test Run

- Before switching it on, test the supply terminal tier (L, N terminals) and grounding points with 500V megaohm meter and check if the resistance is above 1MΩ. It can't be operated if it is below 1MΩ.
- Connect it to the power supply of outdoor units to energize the heating belt of the compressor. To protect the compressor at startup, power it on 12 hours prior to the operation.

Check if the arrangements of the drainpipe and connection line are correct.

The drainpipe shall be placed at the lower part while the connection line placed at the upper part. Heat preservation measures should be taken such as winding the drainpipe esp. in the indoor units with heating insulating materials.

The drain pipe should be made a slope type to avoid protruding at the upper part and concaving at the lower part on the way.

Checkup of Installation

- ☐ check if the mains voltage is matching
- ☐ check if there is air leakage at the piping joints
- ☐ check if the connections of mains power and indoor & outdoor units are correct
- ☐ check if the serial numbers of terminals are matching
- ☐ check if the installation place meets the requirement
- ☐ check if there is too much noise
- ☐ check if the connecting line is fastened
- ☐ check if the connectors for tubing are heat insulated
- ☐ check if the water is drained to the outside
- ☐ check if the indoor units are positioned

Ways of Test Run

Do ask the installation personnel to make a test run. Take the testing procedures according to the manual and check if the temperature regulator works properly.

When the machine fails to start due to the room temperature, the following procedures can be taken to do the compulsive running. The function is not provided for the type with remote control.

- Set the wired controller to refrigerating/heating mode, press "ON/OFF" button for 5 seconds to enter into the compulsive refrigerating/heating mode. Repress "ON/OFF" button to quit the compulsive running and stop the operation of the air conditioner.

Fault Code

Fault Remedies

When any fault appears, consult the fault code of line control or the flashing times for LED5 of computer panel of indoor units/health lamp of receiving window of remote control and find out the faults as shown in the following table to remove all faults.

Error Code	Timer Lights LED5 Flick Times	Error Content
01	1	Ambient sensor TA
02	2	Gas Pipe Sensor TC1
03	3	Liquid Pipe Sensor TC2
04	4	Heat Source Sensor
05	5	EEPROM
06	6	Comm.Error with Outdoor unit
07	7	Comm.Error With controller
08	8	Drainage malfunction
09	9	Repeated address
12	12	50Hz Zero-crossing
14	14	DC Motor
18	18	BS Valve box or 4WV Reverse
20	20	Error from outdoor unit

Move and scrap the air conditioning

- When moving, to disassemble and re-install the air conditioning, please contact your dealer for technical support.
- In the composition material of air conditioning, the content of lead, mercury, hexavalent chromium, polybrominated biphenyls and polybrominated diphenyl ethers are not more than 0.1% (mass fraction) and cadmium is not more than 0.01% (mass fraction).
- Please recycle the refrigerant before scrapping, moving, setting and repairing the air conditioning; for the air conditioning scrapping, should be dealt with by the qualified enterprises.

Qingdao Haier Air Conditioner Electric Co.,Ltd.

Haier Industrial Park,Qianwangang Road,Eco-Tech Development Zone,
Qingdao 266555,Shandong,P.R.C.